

O Christmas Tree Advent Calendar Panel

PLEASE NOTE: Due to an error in the manufacturing process, the fold lines have not been marked on the panels. Please disregard Step 2 of the instructions printed on the panel, and proceed as follows:

From the top edge of the full length pockets, measure down 2 1/2" and mark both edges of the panel. From the bottom edge, measure up 2 1/2" and mark both edges of the panel. This will divide the full length of the pockets into three equal segments approximately 2 1/2" each. Fold on these markings, pin or baste, and press. Repeat for each row of pockets.

Proceed to Step 3 of the instructions on the panel.