

**NORTHCOTT**  
*Cottons that feel like silk*



FREE PATTERN • **Mel's Diner Oven Mitts** • Approx. 14" x 8"  
by Elaine Theriault

**Northcott Canada**  
101 Courtland Avenue  
Vaughan, Ontario L4K 3T5

**Northcott USA**  
1099 Wall St. West, Suite 250  
Lyndhurst, NJ 07071

[www.northcott.com](http://www.northcott.com)

# Mel's Diner Oven Mitts

Finished Size: 14" by 8 "

wof = width of fabric

Fabric requirements	Yards	Cutting Instructions
<b>Fabric A</b> - #22023-52 Motifs on yellow	½ yard	<ul style="list-style-type: none"><li>Main pieces will be cut AFTER the quilting</li></ul>
<b>Fabric B</b> - #22030-36 Star on brown (Trim and lining)	¾ yard	<ul style="list-style-type: none"><li>Cut 1 strip 2 ½" by wof (for binding and tabs)</li><li>Main pieces will be cut AFTER the quilting</li></ul>
Insul-Bright	½ yard	<ul style="list-style-type: none"><li>Pieces will be cut AFTER the quilting</li></ul>


## Oven Mitt Assembly:

- Layer the Insul-Bright between two pieces of Fabric B large enough to make four oven mitt pieces from the template provided. Quilt as desired. (Suggestion: Quilt a grid using diagonal lines in both directions – it's fast and easy.)
- Cut out the paper template for the mitt and tape together at the join.
- Cut out the paper template for the mitt and tape together at the join.
- Using the template, cut FOUR pieces from the quilted fabric. Make sure that you cut two pieces, right side up, then flip the template over and cut two reversed.
- Prepare a tab for hanging by cutting TWO pieces (2" by 4") from the 2 ½" strip of Fabric B.
- Fold each piece in half lengthwise and press. Unfold the pieces and press the two long raw edges towards the center. Fold along the center line to get a small tab that measures ½" by 4". Top stitch along the length of the tab.



- Fold the tab in half and place it on the right side of the mitt facing IN. Note the placement guide on the paper template. Repeat for the second mitt.
- For each of the mitts, place two pieces right sides together. Stitch around the edges using a ¼" seam allowance. Clip the curves and corner. Finish the raw edges of the seams. Turn right side out and press well.
- Fold the remainder of the 2 ½" strip in half lengthwise to create the binding. Sew the binding to the outer edge of each mitt.

NOTE: It is best to NOT prewash preprinted fabrics such as panels and border prints. Fabrics go through many manufacturing processes and there may be some size variations. If you're unable to cut the strips to the size mentioned above, cut the pieces to a size that works for your panels and adjust any other measurements accordingly.



Attach top and bottom pattern pieces together on dotted line

**Cut 2**  
**Cut 2 - Reversed**

**Cut 2**  
**Cut 2 - Reversed**

Tab Placement

Attach top and bottom pattern pieces together on dotted line

