

urban element7.

By Patricia E. Ritter



STAX

FREE PATTERN • 60" x 72 ½" • Designed by Patti Carey • Instructions by Patti Carey of Northcott

Northcott Canada
101 Courtland Avenue
Vaughan, Ontario L4K 3T5

Northcott USA
1099 Wall St. West, Suite 250
Lyndhurst, NJ 07071

www.northcott.com

Stax

Designed by Patti Carey using Northcott's Urban Elementz BASIX by Patricia E. Ritter

Finished Quilt Size: 60" x 72½"

Number of Blocks & Finished Size: 24 blocks 3" high x 60" wide

Skill level: Beginner

Wof = width of fabric

wofq = width of fat quarter

Fabric Requirements	Yards	Cutting Instructions
10 prints from the <i>Urban Elementz – BASIX</i> collection (#21462-64 & 84, 21463-28 & 58, 21464-28 & 74, 21465-52 & 64, 21620-99, 21621-99)	fat ¼ each	• From each fat ¼, cut 5 strips 3½" x wofq; trim each piece to 20½".
#21619-99 white print	1¼yds	• Cut 12 strips 3½" x wof; from each strip, cut (1) 14¼" piece, (1) 12¼" piece, (1) 8¼" piece and (1) 6¼" piece.
Binding (#21465-74)	½yd	• Cut 7 strips 2¼" x wof; join end-to-end, and press in half.
Backing	3¾yds	• Cut into 2 equal lengths and join selvage-to-selvage.
Batting	A piece	66" x 78"

Piecing: All seams are ¼" unless noted.

1. Sew the 3½" x 20½" pieces together in pairs, sewing along short sides to make units 40½" long, using 2 different fabrics for each pair. Make 24 pairs.


2. Select 12 pairs. Sew a 14¼" white piece to one end and a 6¼" white piece to other end of each pair. Press seams toward pair. Label these units as #1.



3. On the remaining 12 pairs, sew a 12¼" white piece to one end, and an 8¼" white piece to the other end of each pair, pressing seams toward pair. Label these units as #2.



4. Choose 2 units from step 2 and 2 units from step 3. Sew them together in the following order: #1, #2 rotated 180°, #2, #1 rotated 180°



Press the seams in one direction. Repeat with the remaining units to make 6 segments of 4 units each.

5. Sew the 6 segments together. The quilt top should be approximately 60" wide x 72" long.

6. Layer the prepared backing, batting and quilt top. Baste and quilt as desired. Trim edges even with quilt top.

7. Sew the prepared binding to edges of quilt, turn and stitch in place.